



Pipe Cutting Matrix



Pipe Material	Pipe Diameter MM	Cutting Methods					Wet Cut	Dry Cut
		Petrol PowerGrit Saw (Wet Cut Only)	Hydraulic PowerGrit Saw (Wet Cut Only)	Hydraulic PowerGrit Saw on Clamp (Wet Cut Only)	Spitznas Radial Pipe Saw	Spitznas Hydraulic Recip Saw		
		Petrol PowerGrit Saw Click Here	Hydraulic PowerGrit Saw Click Here	Hydraulic PowerGrit Saw on clamp Click Here	Spitznas Radial Saw Click Here	Spitznas Hydraulic Saw Click Here		
Cast Iron & Ductile Iron	100 to 200	✓	✓	✓			✓	
	100 to 300	✓	✓	✓			✓	
	300 to 400		✓		✓		✓	
	400 to 1600				✓		✓	
MDPE & HDPE	Up to 200	✓	✓	✓		✓		✓
	100 to 300	✓	✓	✓		✓		✓
	300 to 1600				✓			✓
PVC & GRP	100 to 300	✓	✓	✓		✓		✓
	300 to 1600				✓			✓
Steel	Up to 300					✓	✓	
	300 to 1600				✓		✓	
Asbestos Cement	100 to 300			✓			✓	
	100 to 600		✓				✓	